



Linebox

Please read all the instructions before you begin.

The XTE-2005 is designed to replace the removable bottom section on the standard NTE-5

master socket as shown in the illustration above. If your socket does not have a split design with a removable section then the socket is either not the master socket or is part of an old installation where the XTE-2005 will not fit.

Removal of the front cover

To start, loosen the two screws on the front of the master socket and carefully remove the cover. If you already have extensions the wiring will be attached to the back of the faceplate. Make a note of the colours of the wires and the terminal number they are connected to.

Carefully cut the securing cable tie to free the cable and carefully remove the wires from the faceplate. If they will not come free cut the wire as close to the connector as possible.

- 2 _____
- 3 _____
- 4 _____
- 5 _____

Making the connections

The XTE-2005 has 6 IDC terminals marked B,A,5,4,3,2. Use an IDC tool to insert (punch) extension wires into the terminals. To connect your existing voice extensions connect the wires to the numbered terminals in the same order as removed from the original faceplate. The extensions connected to the numbered terminals can be used for voice only as the ADSL signal has been filtered out.

If you would like to extend the unfiltered ADSL signal use the terminals labelled B & A. Standard wiring colours and number to letter conversion information is shown in the chart overleaf.

Extension Wires

Number	Letter	Colour
2	B	Blue/White
3	-	Orange/White
4	-	White/Orange
5	A	White/Blue

The table above shows the standard colour scheme. If your wire does not have the same the same colour scheme don't worry simply make sure that the same numbers are connected to each other for example 2-2.

Completing Installation

Use the supplied cable tie to secure the cable to the back of the faceplate.

Look closely at the screws that were removed from the original faceplate to determine if they are coarse self tapping or fine machine screws. Select the same type of screw from the two types supplied with the XTE-2005 and screw the XTE-2005 to the back box.

For further information and advice installing the XTE-2005 and telephone extensions please visit our web site.

www.adslnation.com

XTE-2005

Filtered Master Faceplate

Fits standard UK NTE5 master socket

adsl nation

